



FLY LONDON WOMEN'S FOOTWEAR:

UK	EU	CM
2	35	20.5
3	36	21.5
4	37	22.5
5	38	23.5
6	39	24.5
7	40	25.5
8	41	26.5
9	42	27.5